


Retrieve, Display

Analyze & Export

Greyline Logger

Greyline Logger Software for Windows[™]



Greyline Logger Graph and Table Views

Features

- Retrieve data log files from Greyline instruments by RS232 or RS485 connection or by dial-up modem
- Export log files in CSV text format for use in spreadsheet or database programs
- Export graphs in bitmap and vector formats
- Convert measurement units (e.g. gallons, liters, barrels, inches and mm)
- Create formatted reports with Minimum, Maximum, Average and Totals
- Create flow reports from level data through flumes and weirs
- Create flow reports from level/velocity data files
- View real-time data from Greyline Stingray
- Free with Greyline data logging models!



RELIABLE MEASUREMENT AND CONTROL

Greyline Logger Software Data Retrieval, Display and Analysis

Loaded with Tools for Easy Reporting and Analysis

Channel Setup	X	Chan
Level Offset (m) 0.000 Channel Type Round	Level Offset	Level 0 0.000 Flume T V Noto
Channel ID (m) 1.219	OK Cancel	Parsha Palmer Leopoli Rect. V Rect. V Khafag

Calculates Flow from Level-Velocity log files

Generates Flow Reports from Flumes and Weirs

wÆn

Level

0K

Data Tools Communication Window Help		
Format Flow (USGPM) Data	1 Hour Interval	
Extract Flow (USGPM) Data	4 Hour Interval	
Snapshot	8 Hour Interval	
Apply "Zero" Filter to Flow (USGPM) Data	12 Hour Interval	
Generate Flow Log	24 Hour Interval 🗼	

Generates Flow Reports with Minimum, Maximum, Average and Total

System Requirements

- Greyline Logger software runs on any PC with Windows[™] 98, 2000, ME, NT or XP
- RS232 serial port or USB-to-RS232 converter for log file retrieval
- Modems for log file retrieval by dialup telephone connection

Run the *Greyline Logger* program to retrieve and display data logs on your computer. Display multiple files or "sessions" on your PC in both graph and table formats.





Table + Graph Views

Analyze data on-screen and save as disk files

Reload log files to compare current and past data, or logs from different sites

Greyline data logging instruments include an isolated RS232 serial output, terminal connections, cable and adaptors. Connect directly to the serial port on your PC or Laptop, or by dial-up connection through modems and phone lines.



Level-Velocity Log Files

View separate level, velocity and temperature data from Greyline Area-Velocity instruments

No Cal Ver Consume Data Tala Conversion Ver D Cal Ver Consumer Constant Part Part Constant Constant Constant Const Constant Constant Constant Constant Constant Constant Constant Constant Constant Constant Constant	der mit Vergelander Vergeland
	International Control Control Control Level 40 41 55 30 22 4 23 4 24
	16 10 10 10 10 10 10 10 10 10 10

Real-time Display

View Level, Velocity and Temperature readings in real-time from Greyline Area-Velocity instruments



Canada: 16456 Sixsmith Dr., Long Sault, Ont. K0C 1P0 Tel: 613-938-8956 / 888-473-9546 Fax: 613-938-4857 USA: 105 Water Street, Massena NY 13662 Tel: 315-788-9500 / 888-473-9546 Fax: 315-764-0419 E-mail: info@greyline.com Web Site: www.greyline.com RELIABLE MEASUREMENT AND CONTROL